

Digital servo amplifier digifas™ 7200 series



Assembly / Installation / Commissioning

Version 03/98

Previous editions

Edition	Comments
11 / 94	First edition
03 / 96	software version 5L80/5A77, appendix expanded, text revised, -IL-
01 / 97	software version 6L40/6A40, digifas™ 7206 and -BV, -ROD/SSI- and -G- as standard, text revised
03 / 98	SSD-version, parameter list corrected, PC interface (serial connection)

**Technical changes to improve the performance of the equipment
may be made without prior notice!**

Printed in the Federal Republic of Germany 03/98

Mat. no. 83003

digifas™ is a Regd.TM.No 1549070 of Seidel Corporation

All rights reserved. No part of this work may be reproduced in any form (by printing, photocopying, microfilm or any other method) or stored, processed, copied or distributed by electronic means without the written permission of Seidel Corporation.

Contents	Diagram	Page
Contents		A
Safety instructions		C
Directives and standards		D
CE- conformance		D
I General		
I.1 About this manual		I-1
I.2 Prescribed usage of the servo amplifiers		I-1
I.3 Abbreviations used in this manual.		I-2
I.4 Nameplate	- A.4.028,6/10 . . .	I-2
I.5 Equipment description		I-3
I.5.1 The digifas™ 7200 series of digital servo amplifiers		I-3
I.5.2 Digital servo amplifier concept		I-4
I.5.3 Operation directly off a 400V mains		I-4
I.6 Block diagram	- A.4.011,4/14 . . .	I-5
I.7 Frontal view: digifas™ 7200 operating components and connections	- A.4.011,4/9 . . .	I-6
I.8 Technical data of the digifas™ 7200 series		I-7
I.8.1 Permissible ambient conditions, ventilation, mounting position		I-8
I.8.2 Lead cross-sections		I-8
I.8.3 Fuse protection		I-8
I.8.4 LED display		I-9
I.9 System grounds		I-9
I.10 Ballast circuit		I-9
I.11 Motor choke box 3YL-06	- A.4.018,4/1 . . .	I-10
II Installation and commissioning		
II.1 Important instructions		II-1
II.2 Installation		II-2
II.2.1 CE - correct wiring , general diagram.	- A.4.011.1/4 . . .	II-4
II.2.2 Pin assignments for standard unit.	- A.4.011.4/15 . . .	II-5
II.2.3 Wiring diagram standard unit for motor series 6SM27/37/47/57/77	- A.4.011.1/14 . . .	II-6
II.2.4 Wiring diagram standard unit for motor series 6SM45,56	- A.4.011.1/6 . . .	II-7
II.2.5 Wiring example: multi-axis system	- A.4.011.1/10 . . .	II-8
II.2.6 Notes on connection methods.		II-9
II.2.6.1 Using the shield connection terminal clamps	- A.4.029.4/1 . . .	II-9
II.2.6.2 Connecting the SubD9 connector	- A.4.029.4/2 . . .	II-10
II.2.6.3 Using shielded leads with terminals	- A.4.029.4/3 . . .	II-11
II.2.6.4 Using motor cable without brake (amplifier side)	- A.4.029.4/4 . . .	II-12
II.2.6.5 Using motor cable with brake (amplifier side)	- A.4.029.4/5 . . .	II-13
II.3 Commissioning.		II-14
II.4 Parameter description		II-16
II.4.1 General		II-16
II.4.2 Current controller		II-17
II.4.3 Speed controller		II-17
II.4.4 Service functions.		II-18
II.4.5 Display actual value		II-18
II.5 Fault signals, BTB signal		II-18

Contents	Diagram	Page
III Control inputs and outputs		
III.1 Input functions		III-1
III.1.1 Analog inputs		III-1
III.1.2 Digital control inputs		III-1
III.2 Output functions		III-2
III.2.1 Analog outputs		III-2
III.2.2 Digital outputs		III-2
III.2.3 Brake	- A.4.012.3/2	III-3
IV Interfaces and options		
IV.1 Incremental encoder interface (only for units without a CONNECT module)	- A.4.011.3/4	IV-1
IV.2 SSI-Interface, (only for units without a CONNECT module)	- A.4.011.3/5	IV-2
IV.3 PC interface		IV-3
IV.4 Controllable torque limiting, Option -IL-		IV-4
IV.4.1 General, technical data		IV-4
IV.4.2 Important notes		IV-5
IV.4.3 Commissioning		IV-6
IV.4.4 Position of the connectors and control elements	- A.4.011.4/27	IV-6
IV.4.5 Wiring diagram, -IL- option	- A.4.011.1/15	IV-7
V Drawings		
V.1 Mains filters 1EF06 and 3EFxx series	- A.4.011.4/26	V-1
V.2 Connecting of motor series 6SM27/37/47/57/77	- A.4.017.4/15	V-2
V.3 Connecting of motor series 6SM45,6SM56	- A.4.017.4/10	V-3
V.4 Analog input and output circuits	- A.4.011.1/7	V-4
V.5 Digital input and output circuits	- A.4.011.1/8	V-5
V.6 Dimensions digifas [™] 7200	- A.4.011.4/10	V-6
V.7 Installation digifas [™] 7200 in a switchgear cabinet	- A.4.011.4/16	V-7
V.8 Dimensions digifas [™] 7206-BV	- A.4.011.4/17	V-8
V.9 Installation digifas [™] 7206-BV in a switchgear cabinet	- A.4.011.4/18	V-9
V.10 External 5V DC power supply for the position output	- A.4.012.4/31	V-10
V.11 External 24V DC power supply for a max. of three servo amplifiers	- A.4.012.4/32	V-11
V.12 External 24V DC power supply for up to 7 servo amplifiers	- A.4.012.4/33	V-12
VI Appendix		
VI.1 Delivery package, transport, storage, maintenance, disposal		VI-1
VI.2 CE - relevant system components of digifas [™] 7200	- A.4.011.1/18	VI-2
VI.3 Fault-finding		VI-4
VI.4 Glossary		VI-6
VI.5 Parameter list		VI-8
VI.6 Index		VI-9

Safety instructions

Warning signs : you must observe the important instructions in the text, which are indicated by the following symbols:



hazard from electricity
and its effects



general warning
general instruction

- ◆ Only properly qualified personnel are permitted to perform activities such as transport, installation, commissioning and maintenance. Properly qualified persons are those who are familiar with transport, installation, assembly, commissioning and operation of the products, and who have the appropriate qualifications for their job. The qualified personnel must know and observe the following standards and directives:
 - IEC 364 and CENELEC HD 384 or DIN VDE 0100
 - IEC Report 664 or DIN VDE 0110
 - national accident prevention regulations or BGV A2
- ◆ Read the available documentation before carrying out installation and commissioning. Incorrect treatment of the servo amplifier can lead to injury to persons or material damage. It is vital that you keep to the technical data and information on connection requirements (nameplate and documentation).
- ◆ The servo amplifiers contain electrostatically sensitive components which may be damaged by incorrect handling. Discharge your body before touching the servo amplifier. Avoid contact with highly insulating (artificial fabrics, plastic film etc.). Place the servo amplifier on a conductive surface.
- ◆ Do not open the units. Keep all covers and switchgear cabinet doors closed in operation. Otherwise there are deadly hazards with the possibility of severe danger to health or material damage.
- ◆ In operation, depending on the degree of enclosure protection, servo amplifiers can have bare components which are live and hot surfaces. Control and power cables can carry a high voltage even when the motor is not rotating.
- ◆ Never undo the electrical connections of the servo amplifier when it is live. There is a danger of electric arcing and danger to persons and contact.
- ◆ Wait at least two minutes after disconnecting the servo amplifier from the mains supply voltage before touching live sections of the equipment or undoing connections (e.g. contacts, screwed connections). Capacitors can have dangerous voltages present up to two minutes after switching off the supply voltages. To be sure, measure the voltage in the intermediate circuit and wait until it has fallen below 40V.

Directives and standards

Servo amplifiers are components which are intended to be incorporated into electrical machines and plant.

When the servo amplifiers are incorporated into machines or plant, the intended operation of the amplifiers is forbidden until it has been established that the machine or plant fulfills the requirements of the EC Directive on Machines 89/392/EEC and the EC Directive on EMC 89/336/EEC. EN 60204 and EN 292 must also be observed.

In connection with the Low Voltage Directive 73/23/EEC, the harmonized standards of the EN 50178 series are applied to the servo amplifiers, together with EN 60439-1, EN 60146 and EN 60204.

The manufacturer of the machine or plant is responsible for ensuring that the machine or plant meets the limits which are laid down by the EMC regulations. Advice on the correct installation for EMC – such as shielding, grounding, arrangement of filters, treatment of connectors and laying out the cabling – is included in this documentation.

CE-conformance

Conformance with the EC Directive on EMC 89/336/EEC is mandatory for the supply of servo amplifiers within the European Community from the 1st. of January 1996.

The servo amplifiers of the digifas[™] 7200 series have been tested in an authorized laboratory in a specified configuration with the system components described in Chapter VI.2.

Any divergence from the configuration and installation which is described in the documentation means that you will be responsible for the performance of new measurements to ensure that the regulatory requirements are met.

Only if the components as described in Chapter VI.2 are used and the rules for installation in this documentation (Chapter II.1 ff) are followed do we guarantee the conformance of the servo amplifiers with the following standards for industrial areas:

**EC EMC Directive 89/336/EEC
EC Low Voltage Directive 73/23/EEC)**

I General

I.1 About this manual

This manual forms part of the complete documentation for the digifas[™] 7200 series of servo amplifiers. It describes the assembly, installation and commissioning of the standard units of this series, i.e. the versions of the servo amplifier **without** a CONNECT module.

It also includes advice about transport, storage, maintenance and disposal of the equipment.

Other parts of the complete documentation of the digifas[™] 7200 series:

- Installation / operation instructions for the PC-operator software:
BS7200 for digifas[™] 7200 series Order no. 83107
- technical description of the digital interfaces to automation systems:
BIT CONNECT for digifas[™] 7200-SPS series Order no. 83108
PROFIBUS CONNECT for digifas[™] 7200-L2/DP series Order no. 83106
PULSE CONNECT for digifas[™] 7200-STEP series Order no. 83109
CAN CONNECT for digifas[™] 7200-CAN series Order no. 83105

All the necessary documentation for the particular version of the unit is delivered together with the servo amplifier.

This manual makes the following demands on the technical staff:



Transport	:	only by personnel with knowledge of the handling of electrostatic sensitive devices.
Installation	:	only by personnel with training in electrical engineering.
Commissioning	:	only by personnel with extensive knowledge of the fields of electrical engineering and amplifier technology.

I.2 Prescribed usage of the servo amplifiers

Use the digifas[™] 7200 series of servo amplifiers **only** on a three-phase 400V industrial earthed mains supply to amplifier a synchronous servo-motor from the 6SM series.

The servo amplifier may **only** be operated in a closed switch cabinet, taking into account the environmental requirements which are defined in Chapter I.8.1.

The digifas[™] 7200 series of servo amplifiers are **exclusively** intended for driving the 6SM series of brushless synchronous servo-motors under speed or torque control.

The servo amplifiers are installed as components of electrical equipment or machines and may only be operated as integral components of such equipment.

Prepare a hazard analysis of your machine.



Only if the system components as described in Chapter VI.2 are used and the rules for installation in this documentation (Chapter II.1 ff) are followed, we guarantee the conformance of the servo amplifiers with the following standards for industrial areas:

**EC EMC Directive 89/336/EEC
EC Low Voltage Directive 73/23/EEC**

I.3 Abbreviations used in this manual




The table below explains the abbreviations which are used in this manual.

Abbrev.	Meaning	Abbrev.	Meaning
AGND	analog ground	NSTOP	limit-switch input for rot. dir. CCW
BTB	system ready	PELV	protected low voltage
CE	European Community	PGND	ground for the interface used
CLK	clock	PSTOP	limit-switch input for rot. dir. CW
DGND	digital ground	PWM	pulse-width modulation
DIN	German Standards Institute	RAM	memory component
EEPROM	electrically erasable programmable ROM	R _{Ballast}	ballast resistor
EMV	electromagnetic compatibility	RES	resolver
EN	European standard	SPS	programmable logic controller (PLC)
ESD	electrostatic discharge	SRAM	static RAM
IDC	analog current monitor	SSI	synchronous serial interface
IEC	International Electrotechnical Commission	SW	setpoint value
IGBT	insulated-gate bipolar transistor	V AC	AC voltage
ISO	International Standardization Organization	V DC	DC voltage
INC	incremental interface	VDE	Association of German Electrical Engineers
LED	light-emitting diode	VTA	analog speed monitor
NI	zero pulse	XGND	supply voltage ground

I.4 Nameplate

The nameplate depicted below is mounted on the servo amplifier. The information shown below is printed in the individual sections.

Servo amplifier type	Serial number	CONNECT module and options
----------------------	---------------	----------------------------

KOLLMORGEN Seidel		Seidel Servo Drives GmbH D-40489 Düsseldorf		Tel. : 0203/9979-0 Fax : 0203/9979-155			
Typenbezeichnung	Type	Ser. Nr.	Ser. No.	Option	Option		
<input type="text"/>		<input type="text"/>		<input type="text"/>			
Spannungsversorgung	Power Supply	Nennstrom	Nom. Current	Schutzart	Prot. Class		
<input type="text"/>		<input type="text"/>		<input type="text"/>			
 0 0 7 2 0 2 1 2 3 4 5 2				 0 0 0 3 0 7 2 0 7 2 0 1			
Power supply Installed load		Output current in S1 mode		Software version			

I.5 Equipment description

I.5.1 The digifas[™] 7200 series of digital servo amplifiers

The digifas[™] 7200 series of digital servo amplifiers are available in several versions:

Standard version

digifas[™] 72xx series

4 current types, with analog speed-setpoint input, incremental positional output, controllable motor-holding brake. In this standard version there is **no position control capability** in the servo amplifier. This function must be taken over by the automation equipment.

Options* : -IL-, -BV-

BIT CONNECT version

digifas[™] 72xx-SPS series

PLC interface, connection to a simple control via 10 I/O leads, controllable motor-holding brake. Execution of the motion data sets which are stored in the servo amplifier, 4 current types, digital setpoint input from the automation equipment, **positional control** in the servo amplifier.

Option* : -BV-

PULSE CONNECT version

digifas[™] 72xx-STEP series

Pulse-direction interface, connection to a stepper-motor controller or as a slave-controller to a digifas[™] 7200 master-controller with incremental position control, 4 current types, controllable motor-holding brake, digital setpoint input from the automation equipment, **positional control** (cascade control) in the servo amplifier.

Option* : -BV-

PROFIBUS CONNECT version

digifas[™] 72xx-L2/DP series

Connection to PROFIBUS-DP (SINEC-L2-DP), 4 current types, digital setpoint input from the automation equipment, **positional control** in the servo amplifier, controllable motor-holding brake.

Option* : -BV-

CAN CONNECT version,

digifas[™] 72xx-CAN series

Connection to CAN BUS, 4 current types, digital setpoint input from the automation equipment, **positional control** in the servo amplifier, controllable motor-holding brake.

Option* : -BV-

Further explanation of the CONNECT versions can be found in the corresponding Installation and Operating Instructions for the CONNECT module.

* Options : -IL- controllable torque limiting, external accessory unit, see Chapter IV.4
-BV- forced ventilation for digifas[™] 7206 with ballast power > 75W

I.5.2 Digital servo amplifier concept

Operation and parameter setting

Via the parallel interface of a PC using the special operator software BS7200

Power section

- Mains supply : B6 bridge rectifier with current inrush limiter, directly off the 3-phase 400V mains
- Output stage : IGBT-module with electrically isolated current measurement
- Ballast circuit : With electronic monitoring and internal ballast resistor.

Digital functions

- Current and speed control
- Processing of the 14-bit resolver evaluation
- Position output (incremental or SSI) with analog setpoint input
- Communication with the various interface modules and positional control, if an interface module is installed

Easy-to-use functions

adjustable setpoint ramps, limit-switch function, analog monitor outputs

I.5.3 Operation directly off a 400V mains

- Power supply** — Directly off a 3-phase 400V mains **without** transformer, mains filter series 3EFxx
- Fuse protection and phase-failure monitoring by the user
 - Single-phase supply (only for power < 0.5kW) e.g. as a possibility during commissioning or setting-up

- Aux. supply 25V DC** — Electrically isolated, from an external 24V DC- power supply **with** isolating transformer, mains filter 1EF06
- For a short time, at the instant of switching on, the power supply has to provide twice the rated current, so that the power sections can start up the servo amplifiers which are connected.


- Intrinsic safety** — Electrically safe isolation to VDE 0160 (proposed EN 50178) between the mains or motor connection and the signal electronics through appropriate creepage distances and full electrical isolation.
- Soft start, overvoltage detection, short-circuit protection
 - Temperature monitoring of the servo amplifier and motor (when using motors from the 6SM series with our preassembled cables)

Additional interference suppression measures


- Mains filter (see chapter V.1)
- Motor choke (see chapter I.11)

Please consult us in the event of difficulty with an application.

I.6 Block diagram



I.7 Frontal view: digifas[™] 7200 operating components and connections




I.8 Technical data of the digifas™ 7200 series

		digifas™			
Rated specifications	DIM	7201	7202	7204	7206
Rated supply voltage	V~	3 x 80-400 / 50...60Hz +max. 10%			
Rated connected load for S1 operation	kVA	0.9	1.7	2.5	3.5
Rated intermediate circuit voltage	V=	560			
Rated output value (rms value, ± 5%)	A _{rms}	1.5	2.8	4.2	6
Peak output current (max. ca. 5s, ± 5%)	A _{rms}	3,0	5.6	8.4	12
Switch-on threshold of ballast circuit	V	720			
Switch-off threshold of ballast circuit	V	680			
Pulse power of ballast circuit (max. 1s)	kW	3.2			5.8
(Internal) cont. power of ballast circuit	W	75			75 (140)*
Switch-off threshold on overvoltage	V	750			
Form factor of output current (under rated specifications and min. load inductance)	—	1.01			
Min. motor inductance	mH	25	15	8	6
Bandwidth of subordinate current controller	kHz	1			
Clock frequency of output stage	kHz	8.33			
Residual voltage drop at rated current	V	5			
Quiescent power loss, output stage disabled	W	15			
Power loss at rated current (incl. loss in power supply, without ballast dissipation)	W	33	45	60	60
Inputs					
Setpoint, fixed, 14-bit resolution	V	±10			
Max. common mode voltage	V	±10			
Input resistance	kΩ	20			
Max. input drift	μV/K	±30			
Digital control inputs	V	12...36			
	mA	7			
Aux. voltage supply, isolated without brake	V	18...36			
	A	1			
Aux. voltage supply, isolated with brake	V	24 +10%/-5%			
	A	2			
max. output current brake	A	1			
Voltage supply option -BV-	V=	-			24 +10%
	A	-			0.1
Connections					
Control signals	Mini Combicon 3.81 / 12 pole, 1.5mm²				
Power signals	Power Combicon 7.62 / 12-pin, 2.5mm²				
Resolver	SubD 9-pin (socket)				
PC interface	SubD 9-pin (socket)				
Position output ROD/SSI	SubD 9-pin (plug)				
digifas™ - STEP	PULSE CONNECT	Interface : Mini Combicon 3.81 / 12-pin, 1.5mm²			
digifas™ - SPS	BIT CONNECT	Interface : Mini Combicon 3.81 / 12 pin, 1.5mm²			
digifas™ - L2/DP	PROFIBUS CONNECT	Interface : SubD 9-pin (socket)			
digifas™ - CAN	CAN CONNECT	Interface : SubD 9-pin (socket)			
Option -BV-	Combicon 1,5 mm²				
Mechanical					
Weight servo amplifier	kg	2.1			
Dimensions (h x w x d) servo amplifier	mm	275 x 71 x 235			
Weight option -BV-	kg	-			0,3
Dimensions (h x w x d) with option -BV-	mm	-			310x73x236
* >75W with option -BV- only					

* >75W with option -BV- only

I.8.1 Permissible ambient conditions, ventilation, mounting position

Transport temperature/humidity	see Chapter VI.1
Storage temperature/humidity/time	see Chapter VI.1
Supply voltage tolerance	
Power supply	min. 3x80V AC / max. 3x400V AC + 10%
Aux. voltage without brake	min. 18V DC / max. 36V DC
Aux. voltage with brake	24V DC +10%/-5%
Position interface supply	5V DC ± 5%
Ambient temperature at work	0 ... +45°C at rated values +45 ... +55°C with power derating 2.5% / K
Humidity at work	relative humidity 5%... 85%, no condensation
Installation altitude	up to 1000m above mean sea level (m.s.l.) without restriction 1000...2500m above m.s.l. with power derating 1.5% / 100m
Pollution level	Pollution level 2 to EN60204 / EN50178
Protection class	IP 20
Mounting position	generally vertical (observe Chapter V.7 and V.9)
Ventilation	
digifas™ 7201...7204	electronics and heat sink: natural convection
digifas™ 7206	
ballast power max. 75W	electronics and heat sink : natural convection
ballast power 75...140W	forced cooling with option -BV- (see chapter V.8 and V.9)
	Make sure that there is sufficient forced circulation inside the switchgear cabinet.

I.8.2 Lead cross-sections

In accordance with EN60204, we recommend these cross-sections for **single-axis systems**:

AC connection, intermediate circuit	1.5...2.5 mm ² , shielded in case of length > 25cm
motor leads	max. 25m, 1.5 mm ² , shielded 25-100m, 1.0 mm ² , shielded, with motor choke box 3YL-06
Resolver, motor with thermal protection	0.25 mm ² , twisted pairs, shielded, max.100m on request
Analog setpoint, monitor signals, AGND	0.25 mm ² , twisted pairs, shielded
Control signals, BTB, DGND	0.5 mm ²
Holding brake (motor)	min. 0.75 mm ² , shielded, check voltage drop
Option -BV-	1.5 mm ²
+25 V / XGND	1.5 mm ² , shielded, check voltage drop



For multi-axis systems please observe the specific operating conditions of your system (please call us if you have any questions).

If the motor cable is longer than 25m you must use a 4x1mm² cable and a motor choke-box called 3YL-06 manufactured by Seidel.

I.8.3 Fuse protection

AC supply		external power switch for system protection, C or D (motor or transformer) characteristic, set to rated current of amplifier
Aux. voltage 25V	(F103)	internal 2 AT
Intermediate circuit	(F101, F102)	internal 4 AT
Ballast resistor	internal	internal electronic
Option -BV-	internal	internal 250 mA

I.8.4 LED display

Green LED	equipment ready to operate / supply voltage available
Red LED	BTB-relay released, green LED is off, error signal (see Chapters II.5 and V.5), plain text message

I.9 System grounds

The following grounds are available in the system:

- AGND — reference ground for analog inputs/outputs, internal analog ground
- DGND — reference ground for digital inputs/outputs, optically isolated
- XGND — ref. ground for external 25V aux. voltage, optically and inductively isolated
- PGND — ref. ground for external supply for the position interfaces, optically isolated
- GND — ground for internal electronics (also EGND), connected to AGND

I.10 Ballast circuit

When the motor is braking, energy is fed back to the servo amplifier. This energy is converted into heat in the ballast resistor. The ballast resistor is switched in by the ballast circuit. The maximum ballast power depends on the ballast resistor which is used and the ballast power set in the software.

If you would like some help with dimensioning the ballast power required for your system, please talk to our applications department.

Functional description:

- 1.- Single amplifier, not coupled via the intermediate circuit (DC+, DC-)

The circuit starts to respond from a intermediate circuit voltage of 720V.

If the power which is fed back from the motor is higher than the ballast power level which is set, then the servo amplifier signals the status "Ballast power exceeded" and the ballast circuit switches itself off.

At the next internal check of the intermediate circuit voltage (a fraction of a second later) an overvoltage will be recognized and the controller will switch off with an error message "Overvoltage" (see Chapter II.5).
- 2.- Several servo amplifiers coupled via the intermediate circuit circuit (DC+, DC-)

The energy which is fed back into the intermediate circuit from all the motors is dealt with by all the ballast resistors which are connected. This means that the servo amplifier with the lowest ballast switch-on threshold (because of tolerances) will switch in first.

If the regenerative power is lower than the ballast power of this servo drive then the intermediate circuit voltage will not rise any further and no other servo amplifiers will be switched in.

If the ballast power is insufficient then the servo amplifier will signal the status "Ballast power exceeded". The intermediate circuit voltage rises further and the ballast circuit with the next higher threshold will switch in and so on.

If the total regenerative power is larger than the sum of all the ballast powers, then all the servo amplifiers will signal "Ballast power exceeded". The servo drive with the lowest overvoltage threshold (according to tolerance) will switch off with the error message "Overvoltage" and so switch off the complete system via the BTB contact.




Ballast resistor :

- digifas™ 7201...7204 : 150 Ω, 75 W
- digifas™ 7206 : 75 Ω, 140 W (>75W with forced cooling, option -BV-)

I.11 Motor choke box 3YL-06

If the shielded motor cable is longer than 25m, you must use the motor choke box 3YL-06 manufactured by Seidel and a 4x1mm² motor cable.

The motor choke prevents the servo amplifier from extensively high capacitive reactive current.



II Installation and commissioning

II.1 Important instructions

Check the conformance of the servo amplifier and the motor. Compare the rated voltage and current of the equipment. Implement the wiring according to the wiring diagram in Chapter II.2.3 or II.2.4. For units with CONNECT modules, also refer to the connection diagram for the interface in the appropriate CONNECT operating manual.

Take care that, even under worst-case conditions, the maximum permissible rated voltage on the terminals L1, L2, L3 or +DC, –DC is not exceeded by more than 10% (see EN 60204-1, Sec. 4.3.1). Excessive voltage on these terminals can result in destruction of the ballast circuit and the servo amplifier. Use the digifas™ servo amplifier only on a three-phase 400V mains supply and only to drive a synchronous servomotor from the 6SM series.

Fuse protection of the AC mains supply and the 25V supply must be provided by the user. An unnoticed failure of a supply phase can result in an overload and possible destruction of the mains input rectifier. We therefore recommend the use of a power circuit-breaker with phase-failure monitoring (see Chapter I.8.3) .

Make sure that the servo amplifier and motor are properly earthed.

Run power and control cables separately. Recommended distance is more than 20 cm to improve compliance with the limits specified by the EMC regulations.

Install all power cables with an adequate cross-section according to EN 60204. A tabular summary of the recommended cross-sections can be found in Chapter I.8.2 . Use a motor choke box (3YL-06) and a 4x1mm² motor cable if your motor cable is longer than 25m (see chapter I.11). If a motor power cable is used with integrated brake control leads, then the brake control leads must be shielded separately. The shield must be connected at both ends (see Chapter II.2.1 ff).

Loop the BTB contact into the safety circuit of the system. Only so can the monitoring of the servo amplifier be ensured.

Carry out all shielding with large areas (low resistance), using metallised connector housings where possible (see II.2.1 ff). Notes on connection methods can be found in Chapter II.2.6 .

Ensure an adequate supply of filtered cool air in the switchgear cabinet, fed from below. Refer to Chapter I.8.1 .

If the ballast power exceeds 75W, you have to use forced cooling (digifas™ 7206, -BV-)

Alterations in the servo-amplifier settings by means of the operator software are permitted. Any additional tampering with the equipment will invalidate the guarantee.



Caution

Never remove the electrical connections of a servo amplifier which is live.

In some cases this can cause the destruction of the electronics. The residual charge in the capacitors can still have a dangerous level up to 120 seconds after the supply voltage has been switched off.

Measure the voltage in the intermediate circuit and wait until it has dropped below 40V. Even when the motor is standing still, control and power terminals may still be live.

II.2 Installation

Only electrically qualified personnel are allowed to install the servo amplifier.

The installation procedure is described in examples. A different procedure may be necessary or appropriate, depending on the usage of the equipment.

More detailed knowledge can be acquired through our **training courses** (on request).



Caution!

Protect the servo amplifier from inadmissible treatment.

In particular, components must not be bent or insulation clearances changed during transport and handling.

Avoid touching electronic components and contacts.


Caution!

Only install and wire up the equipment in a de-energized condition, i.e. neither the mains supply voltage nor the 25 V auxiliary voltage nor the operating voltage of any other connected equipment may be switched on.

Make sure that the switchgear cabinet is safely disconnected (lock-out, warning signs etc.). The voltages must only be switched on for the first time during commissioning.




Note!

The ground symbol , which will be found in all the wiring diagrams, indicates that you must provide an electrically conductive connection with as large an area as possible between the designated unit and the mounting plate in your switchgear cabinet. This connection is for the suppression of HF interference and must not be confused with the PE-symbol (which is a safety measure to EN 60204) .


Use the following wiring diagrams:

- | | |
|---------------------------------------|---|
| — correct EMC shielding and grounding | : Chapter II.2.1 |
| — Equipment without CONNECT modules | |
| Power and control connections | : Chapter II.2.3 / II.2.4 |
| — Equipment with CONNECT modules | |
| Power connections | : Chapter II.2.3 / II.2.4 |
| Control connections | : wiring diagram in the
CONNECT manual |
| — Multi-axis systems | : example in Chap. II.2.5 |


The following instructions should help you to follow a sensible installation sequence without overlooking any important steps.




CE




II.2.2 Pin assignments for standard unit




II.2.3 Wiring diagram standard unit for motor series 6SM27/37/47/57/77



II.2.4 Wiring diagram standard unit for motor series 6SM45,56




II.2.5 Wiring example: multi-axis system




II.2.6 Notes on connection methods

II.2.6.1 Using the shield connection terminal clamps




Cut off a busbar of the required length from brass bar stock (10x3mm cross-section) and drill the holes as shown.


All the terminal clamps which are needed for connecting the shielding must fit between these drilled holes.



Caution !
Compressed coil springs can be dangerous. Use pliers or grips.
 Compress the coil springs together with the retaining plate and push the busbar through the gap in the holder.




Assemble the busbar, with the shield terminal clamps on it, onto the mounting plate. Use either metal spacer bushes, or bolts with nuts and fittings, to maintain a 50mm clearance. Ground the busbar by means of a single core with 10mm² cross-section (DIN 0178).




Remove the outer covering of the cable over a length of about 30mm, without damaging the shielding braid. Press up the terminal clamp and insert the cable between the busbar and the terminal clamp. **Make sure that there is a reliable contact between the clamp and the shielding braid.**

II.2.6.2 Connecting the SubD9 connector


Example: resolver connector X2




Strip off about 25mm of the outer insulation, taking care not to damage the shielding braid.




Push the free shielding braid back over the outer insulation.



Insulate the back portion with heatshrink sleeving, leaving about 12mm of the braid bare. Strip off the individual cores over a length of 5mm, without damaging the stranded copper.



Crimp the contacts to the individual cores using a special crimping tool. Put the contacts into the SubD plug, according to the wiring diagram in Chapter II.2.3 or II.2.4 (observe the core colours). Check the assignments afterwards.




Attach the cable to the plug housing, using the metallic cable grip. The cable grip must seat on the bare shielding braid with a good contact. Place the knurled screw in position.

Note !


When the two halves of the housing have been put together, they cannot be separated again without damage !
Place the SubD plug in the groove of the housing half (pin 1 at bottom) and close up the housing.

II.2.6.3 Using shielded leads with terminals


Example : analog lead




Strip off about 60mm of the outer insulation, taking care not to damage the shielding braid.



Cut back the shielding braid to a length of about 20mm.




Push back the bare shielding braid over the outer insulation.




Shield connection by stranded cable:
Strip off an individual core (e.g. H05V-K 1mm²). Wind the bared strands around the shielding braid and solder it carefully to the braid, without overheating the plastic outer insulation.

Shielding terminal clamp:
Not applicable, see Chapter II.2.6.1




Strip off the individual cores over a length of 10mm, without damaging the copper strands. Put wire end ferrules over the ends of the cores. Use heatshrink sleeving to insulate the braiding.


II.2.6.4 Using motor cable without brake (amplifier side)




Strip off about 140 mm of the outer insulation (pos. 1), taking care not to damage the shielding braid.



Cut back the shielding braid to a length of about 20 mm.




Push back the bare shielding braid over the outer insulation. Strip off about 110 mm of the inner insulation (pos. 2), taking care not to damage the individual cores. Cut back the individual cores 1, 2 and 3 to a length of 110 mm.



Insulate the back portion with heatshrink sleeving (pos. 3).


Use heated air for shrinking.

Strip off the individual cores over a length of 10 mm, without damaging the stranded copper.




Put ring labels (pos. 4) over the corresponding cores. Put wire end ferrules (pos. 5) over the ends of the cores.


II.2.6.5 Using motor cable with brake (amplifier side)




Strip off about 140 mm of the outer insulation (pos. 1), taking care not to damage the outer shielding braid.




Cut back the outer shielding braid to a length of about 20mm. Cut back the inner shielding braid (brake cores) to a length of about 40mm.



Push back the outer bare shielding braid over the insulation. Wind the inner shielding braid round the outer shielding braid (electrical contact). Push back the filling material and the protection folio over the insulation. Cut back the individual cores U, V, W to a length of 110mm, BR1 and BR2 to a length of 130mm.



Insulate the back portion with heatshrink sleeving (pos. 2). Use heated air for shrinking. Strip off the individual cores over a length of 10mm, without damaging the stranded copper.



Put ring labels (pos. 3) over the corresponding cores. Put wire end ferrules (pos. 4) over the ends of the cores.

II.3 Commissioning

The commissioning of servo amplifiers can only be carried out by qualified personnel with extensive knowledge of the fields of electrical engineering and amplifier technology.

The method of commissioning is described in an example. A different method may be appropriate or necessary, depending on the usage of the equipment.

In the case of multi-axis systems, each amplifier must be commissioned individually.



Caution !

Check that all live connection components are protected against accidental contact. Dangerous voltages can occur up to 750V.

Never disconnect the electrical connections of a servo amplifier which is live. The residual charge in the capacitors can still have a dangerous level up to 120 seconds after the mains supply has been switched off.

The amplifier heat sink can reach a temperature of 80°C in operation. Check (measure) the temperature of the heat sink. Wait until it has cooled down to 40°C before touching it.



Caution !

If the servo amplifier has been stored for longer than 1 year, the DC-link capacitors must be re-formed.

In this case, undo all the electrical connections.

Feed the servo amplifier for about 30min from single-phase 230V AC to the terminals L1 / L2. The capacitors will then be re-formed.



Further information on commissioning :

The adjustment of parameters and the resulting effects on the control characteristic are described in the operating manual for the operator software BS7200.

The commissioning of the CONNECT modules is described in the corresponding manual.

More detailed knowledge can be acquired through our training courses (on request).

The following instructions should help you to follow a sensible installation sequence without endangering personnel or machinery.

	check installation	see Chapter II.2. De-energize the servo amplifier.
	disable Enable Signal	0V on terminal X3/16
	switch on 25V aux. voltage	24V DC on terminal X1/1 and ground on terminal X1/2 The green LED light up after the initialisation sequence (approx. 0.5s) (see Chapter I.8.4)
	switch on PC start operator software	See operating manual for the operator software BS7200. The parameters which are stored in the SRAM of the servo amplifier are transferred to the PC.
	check the displayed params. and correct if necessary	Caution ! Check the parameters described below especially carefully. If you do not observe these basic values, parts of the system may be damaged or destroyed.
	no. of motor poles	: must match the motor (manual for 6SM motors)
	no. of res. pole pairs	: must match the motor (manual for 6SM motors)
	I _{RMS}	: maximum is the standstill current I ₀ of the motor (as per nameplate)
	I _{PEAK}	: maximum is 4 x the standstill current I ₀ of the motor
	final speed	: maximum is the rated speed of the motor (as per nameplate)
	check the safety devices	Caution ! Make sure that personnel or machinery cannot be endangered by any unexpected movement of the amplifier.
	switch on mains power	by the ON/OFF switch on the contactor equipment
	setpoint to 0V	without CONNECT module: on terminal X3/1-2, with CONNECT module: function "const. speed" with n = 0min ⁻¹
	Enable	24V DC on terminal X3/16, motor is stopped with standstill torque
	Setpoint	without CONNECT module installed : - analog setpoint, recommended 0.5V on terminal X3/1-2 with CONNECT module installed : - carry out "REVERSING MODE" function in the "SERVICE" menu, with the given default values (reversing at 100 rpm, change direction every 0.5s)
	Optimization	If the motor oscillates, this is dangerous for the motor ! The Kp parameter in the "Speed" must be reduced. for speed and current controllers, see BS7200 operating manual
	start up CONNECT-module	see corresponding CONNECT operating manual

II.4 Parameter description

A brief description of the parameters is given. Detailed explanations can be found in the operating manual for BS7200.

II.4.1 General

Motor pole no. [-]

The current setpoint entry can be adjusted for operating 2- to 12-pole motors. Changes are only possible when the Enable signal is inactive.

Language [-]

The operator language can be selected from: English, German, French.

Resolver pole-no. [-]

Switches the no. of resolver poles to operate 2/4/6-pole resolvers. Only for amplifiers without Connect module. Changes are only possible when the Enable signal is inactive.

I/O [-]

Determines the function of the I/O terminal X3/15, see Chapter III.1.1 and III.2.2.

Ballast power [W]

Sets the ballast power.

Brake [-]

The motor holding brake can be operated from the servo amplifier.

ROD/SSI [-]

Select the type of interface or switch off the interface if position output is not in use.

NI-offset [increment]

Only accessible when the interface is set to ROD. Determines the position of the zero pulse within a turn. Input referred to zero crossing of the resolver and the preset resolution

ROD code [-]

Only accessible when the interface is set to ROD.

Determines whether the output is in decimal or binary code.

Resolution [Inkr./Umdr.]

Only accessible when the interface is set to ROD.

Determines the no. of increments per turn which are output.

SSI code [-]

Only accessible when the interface is set to SSI.

Determines whether the output is in binary or GRAY-code.

SSI clock [kHz]

Only accessible when the interface is set to SSI. Determines the SSI clock rate and the quiescent level of the clock line. Setting : 200, 1500, 200 inverted, 1500 inverted.

II.4.2 Current controller

 I_{rms} , root mean square current [A]

Sets the desired rms output current.

 I_{peak} , peak current [A]

Sets the desired peak output current according to requirements.

 I_t threshold, signal threshold [%]

Monitors the actual rms current required.

 K_p , P-gain [-]

Determines the proportional gain of the current controller.

 T_n , integration time [ms]

Determines the integration time constant / integral-action time of the current controller.

II.4.3 Speed controller

 K_p , P-gain [-]

Determines the proportional gain (also known as AC-gain).

 T_n , integration time [ms]

Determines the integration time constant / integral-action time.

PID-T2, second time constant [ms]

Influences the P-gain at medium frequencies.

SW offset [mV]

For the offset compensation of CNC controls and the analog input.

SW ramp + [ms]

Delays the rate of rise of the setpoint value during **acceleration**.

SW ramp – [ms]

Delays the rate of fall of the setpoint value during **braking**.

Speed limit [min^{-1}]

Determines the normalization of the actual value for speed.

DC monitor [-]

Selects the output of IDC- or VTA-monitor at terminal X3/23.

Limit switch, Stop [-]

The limit switch inputs can be activated or deactivated together or individually.

The Stop function enables a controlled, drift-free standstill with the standstill torque.

Start Phi, phase shift [min^{-1}]

Compensates the inductive phase shift between motor current and motor voltage.

Limit Phi, phase shift [$^{\circ}\text{electr.}$]

The phase shift is increased linearly between the start speed and the final speed up to the final value of Phi.

T tacho, tachometer time constant [ms]

Influences the speed feedback by a low-pass response.

Speed steadiness [-]

Improves the smooth running qualities for drive applications with a constant speed.

II.4.4 Service functions

The service functions are auxiliary functions for optimizing the controller parameters.

Constant speed

Drive runs with constant speed. The analog setpoint input is inoperable.

Constant current

Drive runs with constant current, under current control. The analog setpoint input is inoperable.

Reversing mode

Drive runs in reversing mode. The analog setpoint input is inoperable.

II.4.5 Display actual value

Internal temperature

The internal temperature is displayed in °C.

Heat sink temperature

The temperature of the heat sink is displayed in °C.

Intermediate circuit voltage

The intermediate circuit voltage which is produced in the servo amplifier is displayed in V.

I²t

The momentary effective load is displayed in % of the preset rms current value.

Ballast power

The actual ballast power is displayed in W.

Speed

The actual speed of the motor is displayed in min⁻¹

Current: actual value

The momentary value of the rms output current (active component) in A

Rotational angle

Displays the actual rotational angle of the rotor (only for $n < 20 \text{ min}^{-1}$) in °mech and counts, referred to the mechanical zero point of the measuring system.

Operating time

Counts the hours of operation of the servo amplifier.

II.5 Fault signals, BTB signal

All fault messages are signalled by the red collective display LED on the front panel and displayed on the PC screen.

All faults result in opening of the BTB contact and a switch-off of the output stage.

- | | |
|--|---|
| — undervoltage in intermediate circuit | : limit set to 65V by the manufacturer |
| — overvoltage in intermediate circuit | : limit set to 750V by the manufacturer |
| — output stage fault | : fault in the output stage |
| — aux. voltage fault | : internal aux. voltage not correct |
| — heat sink temperature too high | : limit set to 80°C by the manufacturer |
| — Internal temperature too high | : limit set to 70°C by the manufacturer |
| — motor temperature too high | : limit set to 145°C by the manufacturer |
| — brake fault | : short-circuit |
| — resolver error | : cable break or similar |
| — line to earth fault | : line to earth fault in the motor or motor cable |

III Control inputs and outputs

III.1 Input functions

III.1.1 Analog inputs

Setpoint input SW

The servo amplifier is equipped with a decoupled differential input for an analog setpoint. It is set for a differential input voltage of max. ± 10 V, resolution 1mV. Ground reference: AGND, terminal X3/17.

A positive voltage on terminal X3/1 with regard to terminal X3/2 produces a clockwise rotation of the motor shaft (looking at the shaft). The common-mode voltage range (important to avoid earth loops) amounts to an additional ± 10 V, input resistance: 20 k Ω .

III.1.2 Digital control inputs

All inputs are **isolated** and coupled via optocouplers. The ground reference is **Digital-GND** (DGND, terminal X3/12). The logic is designed for +24V/7mA (**PLC compatible**), logic-high level is +12 ... 30V / 7mA.

Enable input E

The output stage of the amplifier is enabled by the Enable signal (terminal X3/16, input 24V, **active high**). The attached motor is torque-free in the disabled state.

PSTOP / NSTOP (limit switch) inputs

Limit switch positive/negative (**PSTOP / NSTOP**, terminals X3/10 and 11), **high level in normal operation** (fail-safe for cable break). A low signal (open) disables the corresponding direction of rotation, **the ramp function remains active**. If the inputs are blocked the I-component of the speed controller will also become ineffective, so that a mechanical demarcation (dead stop) is permissible. This function must be explicitly enabled (parameter LIMIT SWITCH to ON).

If the parameter LIMIT SWITCH is set to STOP, the result is a controlled drift-free standstill of the motor, with the standstill torque M_0 , when the limit switch inputs are disabled (I-component is active).

Programmable input I/O

Terminal X3/15 (I/O) can be programmed by means of the I/O parameter for the following input functions (see Chapter II.2.2 for a wiring example) :

- **RESET** : hardware reset of the servo amplifier (active high)
- **1:1 CONTROL** : servo amplifier operates purely as a current controller (active high)
- **INT. OFF** : switches off the I-component of the speed controller (active high)
- Ground reference : DGND (terminal X3/12)



Warning !

Do not program terminal X3/15 as an output if it is wired up as an input !

III.2 Output functions

III.2.1 Analog outputs

DC-monitor: armature current setpoint IDC and tachometer monitor output VTA

Depending on the setting of the DC-MONITOR parameter, the IDC/VTA output (terminal X3/23) provides either the current setpoint (IDC) or a tachometer voltage (VTA).

IDC preselection

The IDC monitor provides $\pm 10V$ at \pm **peak equipment current** (sinusoidal rms value) referred to AGND.

The output is the equivalent to the **active** current value, which is approximately **proportional** to the **motor output torque**. Output resistance: $2.2k\Omega$, resolution: 8bit.

VTA preselection

The output provides $\pm 10V$ referred to AGND at the preset final speed limit.

Output resistance: $2.2k\Omega$, resolution: 10 bit.

III.2.2 Digital outputs

Ready-to-operate contact BTB

Ready-to-operate (**BTB**, terminal X3/21 and 22, **max. 60V/0,5A DC**) is signalled via a **floating** relay contact. The contact is **closed** when the amplifier is ready for operation. The signal is **not** affected by the enable signal or the I^2t limit.

Programmable output I/O

Terminal X3/15 (I/O) can be programmed by the I/O parameter for the following output functions (see Chapter II.2.2 for a wiring example):

- **I2T** : signals that the preset I^2t threshold (high level) has been reached
- **BALLAST** : signals that the preset ballast limit (high level) has been exceeded

Ground reference: DGND (terminal X3/12)




Warning !

Do not program terminal X3/15 as an input if it is wired up as an output !

III.2.3 Brake

A 24V holding-brake in the motor can be operated directly from the servo amplifier. The braking function must be explicitly enabled by using the BRAKE parameter: setting WITH. The diagram below shows the timing and functional relationship between the ENABLE signal, speed setpoint, speed and braking force.



During the internal ENABLE delay time of 50ms the speed setpoint of the servo amplifier is run down to 0V along a 10ms ramp.

The rise and fall times of the holding brake which is built into the motor are different for the individual motor versions of the 6SM series of motors (see the manual for 6SM motors).

This page has been deliberately left blank

IV Interfaces and options

IV.1 Incremental encoder interface (only for units without a CONNECT module)



The incremental encoder interface is included as part of the delivery package for servo-drives which do not have a CONNECT module (standard version). Set the parameter ROD/SSI to ROD with the operator software BS7200.

The position of the motor shaft is calculated in the servo-amplifier from the cyclically-absolute 14-bit information of the resolver digital converter. Pulses are derived from this information which are compatible to the incremental encoder. Two pulse trains (signals A and B) which are electrically set off by 90° and a zero pulse are available at the SubD connector. You can choose between 500, 512, 1000 and 1024 pulses per turn (parameter: RESOLUTION).

The position of the zero pulse can be adjusted over one mechanical turn and stored (parameter: NI-OFFSET). The zero pulse can only be set with A=B=1, so as to maintain compatibility with normal commercial encoders.

The power for the drivers is provided by an external supply voltage (GND: X5.1 and +5V: X5.8). **PGND must be connected to the control.**

Incremental encoder interface : connections and signal definitions



Edge spacing $a \geq 8 \mu\text{s}$

$U_H \geq 3.7\text{V}/-20\text{mA}$

$U_L \leq 0.8\text{V}/+20\text{mA}$

Edge steepness $t_v \leq 0.1 \mu\text{s}$

Delay N-I- $t_d \leq 0.1 \mu\text{s}$

Scanning frequency $> 160\text{kHz}$

Limit speed 6000 rpm

IV.2 SSI-Interface, (only for units without a CONNECT module)

The SSI position interface is included as part of the delivery package for servodrives which do not have a CONNECT module (standard version) . Set the ROD/SSI parameter to SSI with the operator software BS7200.

The signal sequence can be output in **Gray** code (standard) or in **Binary** code. Set the SSI-CODE parameter by using the operator software or the operating keys.

Operate the interface off an external supply voltage (GND : X5.1 and +5V : X5.8).

PGND must be connected to the control.


A serial signal is read out synchronously by the interface at a clock rate of max. 1.5 MHz. You can adapt the servo-amplifier to the clock frequency of the SSI evaluation by using the SSI-CLOCK parameter (200 kHz or 1.5MHz and reversed).

The position of the motor shaft is now calculated from the cyclically-absolute 14-bit information of the resolver digital converter. A position output which is compatible to the usual data format for normal commercial SSI absolute encoders is generated from this information. This synchronous, serial, cyclically-absolute 12-bit information is output on the SubD connector X5.

24 bits are transmitted. The most significant 12 bits are permanently set to ZERO, the least significant 12 bits contain the position output. The interface has to be read like a multi-turn encoder, but supplies valid single-turn data.

SSI-Interface: connections and signal definitions:

The count direction for the SSI interface is set to be upwards for clockwise rotation, looking along the motor axis.



IV.3 PC interface

With the operating software BS7200 you can carry out the setting of the operating, positional, and motion parameters, using a normal commercial personal computer (PC).

The PC interface (X6) of the amplifier is connected with the parallel or serial port of the PC by a 9-core special cable.

Connect / disconnect only while all supply voltages are switched off.

The interface in the servo amplifier is electrically isolated by optocouplers.

Connection to a parallel port :

Use our special 9-core interface cable

Connection to a serial port :

Use our special serial cable with power pack.

Minimum requirements for the PC :

Processor	:	80386 or higher
Clock	:	16 MHz or higher
Operating system	:	MS-DOS (3.3 or higher)
Graphics adaptor	:	VGA
Monitor	:	s/w or colour
Disk drive	:	floppy 3.5", hard disk (C:)
Main memory	:	at least 1MB, there must be at least 400K of contiguous memory in the conventional (640K) memory area
Interface	:	one free port (LPT1:, LPT2:, COM1: or COM2:)
		LPT1: adress 378_H COM1: adress 3F8_H
		LPT2: adress 278_H COM2: adress 2F8_H
System configuration	:	Buffers : min. 30
(config.sys)		Files : min. 30
		Stacks : 0,0 or not defined
		Environment : Size of environment (/E:xxxx) must be defined, min. 1024 byte. Correct syntax runs:
		shell=command.com /E:1024
		if necessary, specify path of <i>command.com</i> .

Further advice and an illustration of the special cables can be found in the manual for the BS7200 operating software.

IV.4 Controllable torque limiting, Option -IL-



Only possible for units without a CONNECT module.

IV.4.1 General, technical data

With the -IL- option you can limit the torque of the motor which is connected to the digifas[™] to a freely selectable value which is less than the pulse torque, with the aid of a DC control voltage. This is achieved by changing the current setpoint by means of an external analog speed-control loop.

The electronics is contained in a separate casing.

Assembly	:	— on top-hat rails EN 50022-35 or C-rails, in the immediate vicinity of the servo amplifier
Dimensions	:	— H x W x D (without top-hat rail) : 111 x 145 x 90 mm
Connections	:	— two 8-pin Combicon connectors for control signals, setpoints and auxiliary voltages — SubD 9-pin socket for pulse encoder signals from digifas [™] — SubD 9-pin plug to transfer the pulse encoder signals to higher-level controls
Inputs	:	— 2 differential amplifiers for 2 speed-setpoints $\pm 10V = \pm$ final speed SW1 fixed, SW2 can be decreased by P302, both SW are added — 1 differential amplifier for current limit 0 ... 10V — aux. supply voltage +25V DC/ 210 mA, XGND — enable via optocoupler, DGND — pulse encoder signals from digifas [™] , PGND
Outputs	:	— current setpoint $\pm 10V$, AGND — aux. voltage +10V DC/ 5mA, AGND — pulse encoder signal for control via optocouplers, PGND
Potentiometer	:	— P302 : to reduce setpoint 2 0 ... 100% — P303 : offset (speed drift) $\pm 10mV$ — P304 : fine adjustment of speed $\pm 12\%$ — P305 : AC gain (P-gain) 3 ... ∞
Solder link LB1:	:	— open : final limit speed 3000 rev/min (standard) — closed : final limit speed 6000 rev/min
LEDs	:	— display the logical state of the pulse encoder signals
Fusing	:	— F1, 630 mAF, to protect the aux. supply voltage

IV.4.2 Important notes

Connect up the unit according to the wiring diagram in Chapter IV.4.5.

The unit is supplied from the auxiliary voltage (terminals +25V, XGND) which is also available in the servo amplifier. Internally, this is electrically connected to the analog ground (AGND). There is an internal fuse for the positive pole. Both poles are decoupled via HF chokes.

If you want to use the pulse encoder signals in the control system, then the driver circuitry on the option board must be provided with a 5V supply (see Chapter IV.4.5).

The analog speed controller is normalized for 1024 pulses / turn. You can use the soldered link LB1 to set the speed controller to a final limit speed of 3000 rev/min (LB1 open) or 6000 rev/min (LB1 closed).

Close all the hardware limit switches in the higher-level control and combine the signals in an AND function. Join the servo amplifier inputs PSTOP and NSTOP together (see Chapter IV.4.5). Connect the output of the AND function to the joined inputs PSTOP/NSTOP. In order to be able to amplify away from an activated limit switch, the controller must produce a speed setpoint value with the correct polarity sign for traversing away from the activated limit switch and then 24V must be applied to the bridged limit switch.

In the event of an overload of the servo amplifier, the effective current limit within the servo drive (I^2t) remains active.



Caution !

The amplifier can run away if the pulse encoder cable from the servo amplifier to the IL module is interrupted (e.g. by mechanical damage to the cable). Take account of this in the controller program.

The following table shows the relationship between the applied current limit I_{lim} and the current setpoint I_{setp} which is produced:

Current limit input I_{lim}	negative voltage	open	0 ... +10V
Current limit output I_{setp}	0.3 % I_{peak}	0.3 % I_{peak}	0.3 ... 100 % I_{peak}

If the enable input is not controlled, then the result is always $I_{setp} = 0.3 \% I_{peak}$.

IV.4.3 Commissioning

Our applications department can help you with commissioning.

Preparation

- switch off the supply voltages
- detach plug X4 from the servo amplifier
- check LB1 (final speed), change solder link if necessary
- set enable signal to 0V
- switch on aux. voltage 25V DC and PC, start operator software BS7200


Setting parameters

- set parameter “ROD resolution” to 1024 incr./turn
- adjust parameter “Final limit speed” to the setting of LB1
- set parameter “I/O” to 1:1 control
- set parameter “Ramp +” to 2ms
- set parameter “Ramp –” to 2ms
- store the parameter set in the EEPROM
- switch off the 25V DC aux. voltage


Optimization

- connect plug X4 to the servo amplifier, switch on the voltages
- optimization : offset adjustment with potentiometer P303
AC gain adjustment with potentiometer P305
continue in the same way as the corresponding description in the BS7200 manual.

IV.4.4 Position of the connectors and control elements




IV.4.5 Wiring diagram, -IL- option



This page has been deliberately left blank

V Drawings


V.1 Mains filters 1EF06 and 3EFxx series





	1EF06	1EF3,5	3EF05	3EF08	3EF16
Rated voltage	24V DC	230V AC	400V AC		
Rated current	6 A	3,5 A	5 A	8 A	16 A
A /mm	65,5	98	190	220	240
B /mm	41	75,9	150	180	200
C /mm	9,6	12	17	17	17
D /mm	0,5	–	0,75	0,75	0,75
E /mm	24,1	38,1	50	60	65
F /mm	9,1	15,5	85	115	115
J /mm	45	–	105	115	150
K /mm	28	55,6	75	85	119,5
L /mm	37	87	90	100	135
M /mm	3,5	5,3	6,5	6,5	6,5
V			M6	M6	M6
W /mm ²	Faston	Faston	4	4	4
Weight /kg	0,065	0,3	1,1	1,8	1,8

V.2 Connecting of motor series 6SM27/37/47/57/77


Top view
build-in plug
Resolver




Top view
build-in plug
power



connector round, 12-poles
(Mat.-No.: 85080)



Sub-D connector 9-poles
(Mat.-No.: 81783)




Res. cable f. 6SM
with connector


Length	Mat.No.
5m	84972
10m	84973
15m	84974
20m	84975

4 x 2 x 0,25
shielded, twisted pairs
on request max. 100m

V.3 Connecting of motor series 6SM45,6SM56




12-pin connector
(Mat.-No.: 85080)



4 x 2 x 0,25
shielded, twisted pairs
on request max. 100m


Sub-D connector 9-pin
(Mat.-No.: 81783)





Shield connected to
metallic cover internally

Length	Mat.No.
5m	84972
10m	84973
15m	84974
20m	84975


Res. cable f. 6SM
with connector
longer cable on request




V.4 Analog input and output circuits




V.5 Digital input and output circuits







V.7 Installation digifas™ 7200 in a switchgear cabinet



V.8 Dimensions digifas™ 7206-BV





V.9 Installation digifas[™] 7206-BV in a switchgear cabinet



V.10 External 5V DC power supply for the position output



5V DC / 0.25A



Specifications

Input voltage	110/220V +10% -15%
Input current	0.12/0.06 A
Frequency	50/60 Hz
Primary fuse	0.2 AM (5x20mm)
Output voltage	5 V DC \pm 2%
Max. output current	250 mA
Eff.residual ripple	< 0.2%
Output fuse	0.5 AM (5x20mm)
Test voltage	according to VDE 0550
Temperature range	-20...+60°C
Type of mounting	DIN rail to EN50022 suspended vertically
Weight	0.5 kg
Order no.	83050

5V DC / 2A





Specifications

Input voltage	110/220V +10% -15%
Input current	1.1/0.6 A
Frequency	50/60 Hz
Primary fuse	1 AT (5x20mm)
Output voltage	5 V DC \pm 2%
Max. output current	2 A
Eff.residual ripple	< 0.1%
Output fuse	4 AM (5x20mm)
Test voltage	according to VDE 0550
Temperature range	-20...+60°C
Type of mounting	DIN rail to EN50022 suspended vertically
Weight	2.5 kg
Order no.	83033

V.11 External 24V DC power supply for a max. of three servo amplifiers

24V DC / 5A




Specifications

Input voltage	230/400V according to DIN IEC 38A ($\pm 5\%$)
Input current	0.8/0.45 A
Frequency	50/60 Hz
Output voltage	24V DC. $\pm 10\%$ secondary reconnectable
Max. output current	5 A
Eff.residual ripple	< 5%
Output fuse	8 AM (5x20mm)
Test voltage	according to VDE 0551
Temperature range	-20...+60°C
Type of mounting	Keyhole suspension, screwable suspended vertically
Weight	4 kg
Order no.	83034

V.12 External 24V DC power supply for up to 7 servo amplifiers

24V DC / 20A




Specifications

Input voltage	3 x 400V AC $\pm 10\%$
Input current	ca. 1,1A
Frequency	50/60 Hz
Primary fuse	none
Output voltage	24 V DC $\pm 1\%$
Max. output current	20 A
Eff.residual ripple	< 0,1%
Output fuse	short circuit proof
Test voltage	acc. to VDE 0550
Temperature range	-20...+60°C
Type of mounting	mounting plate
Weight	3,5 kg
Order no.	81279

VI Appendix**VI.1 Delivery package, transport, storage, maintenance, disposal**

- Delivery package :**
- 1 digifas[™] 7200 series servo amplifier
 - 3.5" diskette with the operator software BS7200
 - 2 ring cores
 - installation/commissioning manual for digifas[™] 7200
 - BS7200 operating manual
 - installation/commissioning manual for the CONNECT module, if one is built in
- Transport :**
- only by qualified personnel
 - only in the original recyclable manufacturer's packaging
 - avoid shocks
 - temperature $-25 \dots +70^{\circ}\text{C}$, max. 20 K/hr variation
 - humidity relative humidity max. 95% no condensation
 - the servo amplifiers contain electrostatically-sensitive components which can be damaged by incorrect handling.
Discharge yourself before you touch the servo-amplifier.
Avoid touching highly insulating materials (artificial fabrics, plastic wrappings etc.). Place the servo amplifier on a conductive base.
 - if the packaging is damaged, check the unit for visible damage. In such a case inform the shipper and the manufacturer.
- Storage :**
- only in the original recyclable manufacturer's packaging
 - the servo amplifiers contain electrostatically-sensitive components, which can be damaged by incorrect handling.
Discharge yourself before you touch the servo-amplifier.
Avoid touching highly insulating materials (artificial fabrics, plastic wrappings etc.). Place the servo amplifier on a conductive base.
 - max. stacking height 10 cartons
 - storage temperature $-25 \dots +55^{\circ}\text{C}$, max. 20 K/hr variation
 - humidity relative humidity max. 95% no condensation
 - storage duration < 1 year without restriction
> 1 year : the capacitors must be re-formed before commissioning the servo amplifier.
To do this: remove all electrical connections, feed the servo amplifier for about 30 min from single-phase 230V AC on terminals L1 / L2.
- Maintenance :**
- no maintenance required
 - opening the equipment housing invalidates the guarantee
- Cleaning :**
- if the housing is dirty : clean with isopropanol or similar
do not immerse or spray
 - if there is dirt inside the unit : to be cleaned by the manufacturer
- Disposal :**
- the servo amplifier may be reduced to its principal components (aluminium heat sink and front panel, steel housing sections, electronics boards) by undoing all screw connections
 - the disposal should be performed by a certified disposal company.
We can give you suitable addresses.

VI.2 C€ - relevant system components of digifas[™] 7200





Only under the condition that the system components listed below are used and that the commissioning instructions in this documentation (Chapter II.1 ff) are followed, can we guarantee the conformance of the servo amplifier with the following standards for industrial areas:

- EC EMC Directive 89/336/EEC
- EC Low Voltage Directive 73/23/EEC

If there is any deviation from these requirements you must provide your own measurements to demonstrate conformance to the standards.

The item nos. below refer to the system diagram on the opposite page.

Item no.	Designation	Description
1	analog cable	shielded, twisted pairs, 3x2x0.25mm ²
2	shield terminal clamps	various sizes, manuf. Weidmüller, type KLBÜ
3	mains adapter 24VDC/xA	auxiliary voltage supply
4	1EF06	mains filter, manuf. Seidel, single-phase
5	mains cable	shielded, 4x1.5 mm ²
6	3EFxx	mains filter, manuf. Seidel, for various currents
7	digifas™ 72xx	servo amplifier, manuf. Seidel, various versions
8	ROD/SSI cable	shielded, twisted pairs, 4x2x0.25mm ²
9	resolver cable	manuf. Seidel, ready-made, can be trailed
10	EMC-RES-connector	component of resolver cable manuf. by Seidel
11	woven tape	manuf. Seidel, ready-made
12	motor-/brake cable	manuf. Seidel, shielded, can be trailed, with or without integral brake cable, in case of shielded
	motor cable	length ≤ 25m : 1.5mm ²
		length 25m to 100m: 1mm ² with motor choke box
13	EMC-PGxx	PG screwed gland, built into the terminal box of motor series 6SM45,56
	EMC-Power connector	EMC power conn. for motors 6SM27/37/47/57/77
14	6SMxx	synchronous servo-motor, various frame sizes
15	ring core	ferrite ring

x = various value



Make a selection from our price list. Configure your own tailor-made servo system from our individual components.

Our applications department is always available to deal with your queries.

The components listed below do not have any decisive effect on the conformance of single-axis systems to the standards. However, for multi-axis systems item F may need to be shielded, depending on the length.

- A — 7 x 0.5mm², single cores
- B — PC cable, manuf. Seidel
- C — line driver (booster)
- D — earth lead, 1.5 ... 16mm²
- F — length more than 20cm : shielded cable, 7x1.5mm²
length up to 20cm : 5 single cores, 1.5mm²

VI.3 Fault-finding

The table below should be seen as a “First-Aid” box. There may be a wide variety of possible reasons for the occurrence of a fault, depending on the circumstances in your system.

Multi-axis systems may conceal further causes of a fault.

Our applications department can give you further assistance with problems.

Fault	possible causes	ways to remove the cause of the fault
fault signal: comms. fault	<ul style="list-style-type: none"> — wrong cable used — cable inserted into wrong position in the PC or the servo amplifier — wrong PC interface selected — PC amplifier power insufficient — booster defect — booster power pack defect — mains voltage for booster power pack not correct — PC is not grounded 	<ul style="list-style-type: none"> — use the Seidel PC cable — insert the connector into the correct position in the PC or the servo amplifier — correct call in the op. software — use a booster — replace booster — replace power pack — check mains supply — ground the PC
fault signal: undervoltage	<ul style="list-style-type: none"> — mains voltage not present or too low when the servo amplifier is enabled 	<ul style="list-style-type: none"> — enable the servo amplifier only when the mains supply has been switched on
fault signal: overvoltage	<ul style="list-style-type: none"> — ballast power inadequate, ballast power limit was reached, the ballast resistor was switched off. This caused the excessive intermediate circuit voltage. — mains voltage too high 	<ul style="list-style-type: none"> — shorten the RAMP- braking time set the parameter ballast power to 75W / 140W (7206) — connect the intermediate circuits of several amplifiers — use a mains transformer
fault signal: brake	<ul style="list-style-type: none"> — short-circuit in the supply leads to the motor-holding brake — defective motor-holding brake 	<ul style="list-style-type: none"> — remove short-circuit — replace motor
fault signal: output stage fault	<ul style="list-style-type: none"> — motor cable has short-circuit / earth short — motor has short-circuit / earth short — output stage overheated — defect in output stage 	<ul style="list-style-type: none"> — replace cable — replace motor — improve ventilation — return servo amplifier to manufacturer for repair
Fault signal: V-fault (aux. voltage)	<ul style="list-style-type: none"> — the aux. voltage produced in the servo amplifier is defective 	<ul style="list-style-type: none"> — return servo amplifier to manufacturer for repair

Fault	possible causes	ways to remove the cause of the fault
fault signal: resolver	<ul style="list-style-type: none"> — resolver plug not properly connected — break in resolver cable, cable crushed etc. — wrong type of resolver 	<ul style="list-style-type: none"> — check connector — check cable — use two-pole resolver
fault signal: heat sink temperature	<ul style="list-style-type: none"> — permissible heat sink temperature exceeded 	<ul style="list-style-type: none"> — improve ventilation
fault signal: internal temperature	<ul style="list-style-type: none"> — permissible internal temperature exceeded 	<ul style="list-style-type: none"> — improve ventilation
fault signal: motor temperature	<ul style="list-style-type: none"> — thermal cut-out in motor has been activated — resolver connector loose or break in resolver cable 	<ul style="list-style-type: none"> — wait until the motor has cooled down, then investigate the cause of the overheating — use new resolver cable
no motor rotation	<ul style="list-style-type: none"> — servo amplifier not enabled — break in setpoint lead — motor phases swapped — brake not released — amplifier mechanically jammed — no. of motor poles set incorrectly — wrong type of resolver 	<ul style="list-style-type: none"> — apply ENABLE signal — check setpoint lead — correct motor phasing — check braking control — check mechanism — set parameter: motor pole no. — use two-pole resolver
motor runaway	<ul style="list-style-type: none"> — motor phases swapped — with -IL- option: ROD cable defect or not properly connected 	<ul style="list-style-type: none"> — correct motor phasing — check ROD/SSI cable
motor oscillates	<ul style="list-style-type: none"> — gain too high — shielding in resolver cable broken — AGND not wired up 	<ul style="list-style-type: none"> — reduce Kp parameter — replace resolver cable — join AGND to CNC-GND

VI.4 Glossary

B	Ballast circuit	converts excess regenerative energy from the motor during braking into heat in the ballast resistor
C	Clock	clock signal
	Common-mode voltage	amplitude of the disturbance which can be eliminated in an analog input (differential input)
	CONNECT module	module built into the servo amplifier, with integral positional control, which provides special interface variations for the connection to the higher-level control
	Counts	internal count pulses, 1 pulse = 1/4096 of 1 turn
	Continuous ballast power	average power which can be dissipated by the ballast circuit
	Current controller	regulates the difference between the current setpoint and the actual current value to 0. output : power output voltage
D	Disable	removal of the ENABLE signal (0V or open)
E	Earth short	electrically conductive connection between a phase and PE
	Enable	enable signal for the servo amplifier (+24V)
F	Field-bus interface	here: CONNECT module CAN-CONNECT and PROFIBUS-CONNECT
	Final limit speed	max. value of normalized speed at $\pm 10V$
G	GRAY code	special form of binary encoding
H	Holding brake	a brake in the motor which must only be activated at standstill
I	Input drift	temperature and age-dependent changes in an analog input
	I ² t threshold	monitoring of the actual effective current demand I _{rms}
	Incremental encoder interface	position signal by 2 signal with 90° phase difference, not an absolute position signal
	I _{peak} , peak current	effective value of the pulse current
	I _{rms} , effective current	effective value of the continuous current
	Intermediate circuit	rectified and smoothed power DC voltage
K	K _p , P-gain	proportional gain of a control loop
L	Limit switch	limit switch for the traverse path of the machine; implemented as break contact
M	Machine	the sum of all components which are connected together and of which at least one is movable
	Mains filter	external device to divert disturbances on the power leads to PE
	Monitor output	output of an analog measurement value
	Motion block	data packet with all the positional control parameters which are required to perform a movement – only when a CONNECT module is available
	Multi-axis system	machine with several independent amplifier axes

N	Natural convection	free air movement for cooling
	NI pulse	is produced once per turn by incremental encoders, used to establish the zero point for the machine
O	Optocoupler	optical connection between two electrically independent systems
P	P-controller	control loop with purely proportional characteristic
	Phase shift	compensation for the phase lag between the electro-magnetic and magnetic fields in the motor
	PID controller	a control loop with proportional, integral and differential characteristics
	PID-T2	filter time constant for the speed control
	Position controller	regulates the difference between the position setpoint and the actual positional value to 0. output : speed setpoint
	Potential isolation	electrically decoupled
	Power contactor	system protection with phase-failure monitoring
R	Pulse power of the ballast circuit	maximum power which can be dissipated in the ballast circuit
	Reset	new start of the microprocessor
	Resolver-digital converter	conversion of the analog resolver signals into digital information
	Reversing mode	operation with a periodic change of direction
	Ring core	ferrite ring(s) for interference suppression
S	Servo amplifier	device for the control of speed and torque of a servo motor
	Short-circuit	here: electrically conductive connection between two phases
	Speed controller	regulates the difference between the speed setpoint SW and the actual speed to 0. output: current setpoint
	SSI-interface	cyclically absolute, serial positional information
	SW ramp	limitation of the rate of change of the speed setpoint SW
T	T-tacho, tachometer time constant	filter time constant in the speed feedback of the control loop
	Tachometer voltage	a voltage which is proportional to the speed
	Thermal cut-out contact	a temperature sensitive switch which is built into the motor winding
	Tn, I-time constant	integral component of the control loop
Z	Zero pulse	is produced once per turn by incremental encoders, used to establish the zero point for the machine

VI.5 Parameter list

Group	Display text	Remarks	Units	Min	Max	Default	actual value
Current controller	I _{rms}	effective current	A	0,1	I _{enn}	*0,5I_{enn}	
	I _{peak}	peak current	A	0,2xI _{enn}	2xI _{enn}	*I_{enn}	
	I ² t threshold	monitoring threshold	%	0	100	80	
	K _p	p(roportional) gain	-	0,1	8	*1,5	
	T _n	i(ntegr.) time constant	ms	0,1	10	*0,6	
Speed controller	K _p	p(roportional) gain	-	1	61	*(5)10	
	T _n	i(ntegr.) time constant	ms	0,1	9999	*(5)10	
	PID-T2	2. time constant	ms	0,2	25	*(0,6)2,0	
	SW offset	compensation	mV	-120	+120	0	
	SW ramp +	ramp up	ms	2	8000	10	
	SW ramp -	ramp down	ms	2	8000	10	
	final limit speed	final tacho speed	min ⁻¹	800	6000	*3000	
	DC monitor	selection IDC/VTA	-	TACHO	CURRENT	TACHO	
	Limit switch	on/off/stop	-	off/on	stop	off	
	Start Phi	Phasen lead	min ⁻¹	0	final speed	1500	
	Limit Phi	Phasen lead	°electr.	0	45	20	
	T-Tacho	tacho time constant	ms	0,2	100	*(0,2)0,6	
	Speed steadiness	speed steadiness	-	off	on	off	
	Motor pole no.	steps ±2	-	2	12	6	
	Language	operating language	-	German	Engl./French	German	
	Res. pole no.	steps 2/4/6	-	2	6	2	
General	I/O	programmable input/output	-	various	various	RESET	
	Ballast power	ballast power	W	1	75[140]	75	
	Brake	holding brake active	-	without	with	without	
	NI offset	ROD zero-pulse pos.	Incr.	0	resolution	0	
	ROD/SSI	position output	-	ROD/SSI	off	ROD	
	ROD code	ROD output format	-	binary	decimal	bin	
	Resolution	ROD resolution	Incr/turn	512/1024	500/1000	1024	
	SSI code	SSI output format	-	binary	Gray	bin	
	SSI clock	SSI clock rate	kHz	200/200	1500/1500	200	

* variable parameters, specific for different motor types

Values in brackets (x) only for digifas™ 7201

Values in brackets [x] only for digifas™ 7206

Customer

Cabinet no.

Unit no.

Place, date

Signature

VI.6 Index

A	AGND	
	Abbreviation.	I-2
	System Grounds	I-9
	Wiring 6SM45/56	II-7
	Wiring 6SMx7 series	II-6
	Ambient temperature	I-8
	Analog input and output circuits.	V-4
	Assembly	II-3
	Switchgear cabinet with option -BV-.	V-9
	Switchgear cabinet	V-7
B	Ballast circuit	I-9
	Ballast power	I-9
	Display	II-18
	Parameter.	II-16
	BIT CONNECT	I-3
	Brake	
	Diagram	III-3
	Parameter.	II-16
	Power supply	I-8
	Wiring 6SM45/56	II-7
C	BTB	
	Abbreviation.	I-2
	Fault signals	II-18
	Relay contact	III-2
	Wiring 6SM45/56	II-7
	Wiring 6SMx7 series	II-6
	CAN CONNECT.	I-3
	Commisioning	II-14
	Connection methods	II-9
	Constant current	II-18
D	Constant speed	II-18
	Current: actual value	II-18
	DC Monitor	
	Output.	III-2
	Parameter.	II-17
	Wiring 6SM45/56	II-7
	Wiring 6SMx7 series	II-6
	Delivery package	VI-1
	DGND	
	Abbreviation.	I-2
E	System grounds.	I-9
	Wiring 6SM45/56	II-7
	Wiring 6SMx7 series	II-6
	digifas™ -72xx	I-3
	digifas™ -72xx-CAN	
	Connection	I-7
	Description	I-3
	digifas™ -72xx-L2/DP	
	Connection	I-7
	Description	I-3
F	digifas™ -72xx-SPS	
	Connection	I-7
	Description	I-3
	digifas™ -72xx-STEP	
	Connection	I-7
	Description	I-3
	Digital input and output circuits	V-5
	Dimensions digifas™ 7200	V-6
	Dimensions digifas™ 7206-BV	V-8
	Disposal	VI-1
G	EMC	
	Abbreviation.	I-2
	EMC relevant components	VI-2
	EMC wiring diagram.	II-4
	Enable input.	III-1
	Wiring 6SM45/56	II-7
	Wiring 6SMx7 series	II-6
	Fault messages	II-18
	Fuse protection	I-8
	Wiring 6SM45/56	II-7
H	Wiring 6SMx7 series	II-6
	GND.	I-9
	Ground symbol	II-2
	Grounding.	II-3
	CE-Diagram.	II-4
	Wiring 6SM45/56	II-7
	Wiring 6SMx7 series	II-6
	Heat sink temperatur	II-18
	Humidity	
	At work	I-8
I	Storage	VI-1
	Transport	VI-1
	I/O	
	Input.	III-1
	Output.	III-2
	Parameter.	II-16
	Wiring 6SM45/56	II-7
	Wiring 6SMx7 series	II-6
	I ² t	II-18
	I ² t threshold.	II-17
J	IDC	
	Abbreviation.	I-2
	Output.	III-2
	Parameter.	II-17
	Wiring 6SM45/56	II-7
	Wiring 6SMx7 series	II-6
	Installation.	II-2
	Installation altitude	I-8
	Intermediate circuit	II-18
	Technical data	I-7
K	Internal temperature.	II-18
	I _{peak}	II-17
	I _{rms}	II-17
	Kp current	II-17
	Kp speed	II-17
	Language	II-16
	Lead cross-sections.	I-8
	LED	
	Abbreviation.	I-2
	Display	I-9
L	Limit Phi.	II-17
	Limit switches	
	Parameter.	II-17
	Wiring 6SM45/56	II-7
	Wiring 6SMx7 series	II-6
	Location	II-3

Text	Page	Text	Page
M		S	
Mains filters	V-1	Safety instructions.	1-C
Maintenance	VI-1	Setpoint	
Motor choke	I-10	Input.	III-1
Motor choke box	I-10	Technical data	I-7
Motor pole no.	II-16	Wiring 6SM45/56	II-7
Mounting position	I-8	Wiring 6SMx7 series	II-6
Multi-axis system		Setpoint Offset	II-17
Lead cross-sections.	I-8	Setpoint ramp -	II-17
Wiring example	II-8	Setpoint ramp +	II-17
N		Shielding	II-3
NI	I-2	CE-Diagram.	II-4
NI-Offset.	II-16	Wiring 6SM45/56	II-7
NSTOP		Wiring 6SMx7 series	II-6
Input.	III-1	Speed	II-18
Wiring 6SM45/56	II-7	Speed limit	II-17
Wiring 6SMx7 series	II-6	SSI clock	II-16
O		SSI Code	II-16
Operating time	II-18	SSI Interface	IV-2
Option -BV-	I-7	Stacking height	VI-1
Option -IL-	IV-4	Standard version	I-3
P		Start Phi	II-17
Parameter	II-16	Storage	VI-1
PGND		Storage duration	VI-1
Abbreviation.	I-2	Storage temperature	VI-1
System Grounds	I-9	Supply voltage	I-8
Wiring 6SM45/56	II-7	SW	
Wiring 6SMx7 series	II-6	Abbreviation.	I-2
PID-T2.	II-17	Input.	III-1
Pin assignment	II-5	System grounds.	I-9
Pollution level	I-8	T	
Prescribed usage	I-1	T tachometer	II-17
PROFIBUS CONNECT	I-3	Technical Data	I-7
Protection class	I-8	Tn current	II-17
PSTOP		Tn speed	II-17
Abbreviation.	I-2	Transport	VI-1
Input.	III-1	V	
Wiring 6SM45/56	II-7	Ventilation	II-3
Wiring 6SMx7 series	II-6	Ambient conditions	I-8
PULSE CONNECT	I-3	VTA	
R		Abbreviation.	I-2
Re-formation	VI-1	Output.	III-2
Resolution	II-16	Parameter.	II-17
Resolver		Wiring 6SM45/56	II-7
Wiring 6SM45/56	II-7	Wiring 6SMx7 series	II-6
Wiring 6SMx7 series	II-6	W	
Resolver pole no.	II-16	Wiring	II-3
Reversing mode		CE-Diagram.	II-4
Commissioning	II-15	Multi-axis system	II-8
Service function.	II-18	Wiring diagram	
ROD Code	II-16	6SM45/56	II-7
ROD Interface		6SMx7 series	II-6
Description	IV-1	X	
Wiring 6SM45/56	II-7	XGND	
Wiring 6SMx7 series	II-6	System grounds.	I-9
ROD/SSI	II-16	Wiring 6SM45/56	II-7
Rotation angle.	II-18	Wiring 6SMx7 series	II-6

This page has been deliberately left blank

Vertrieb und Service / Sales and Service / Agence et Services

<u>Bundesrepublik Deutschland / Germany / Allemagne</u> Kollmorgen Seidel GmbH & Co. KG Verkaufsniederlassung Nord Wacholderstr. 40-42 40489 Düsseldorf Tel.: +49(0)203 - 99 79 214 Fax: +49(0)203 - 99 79 182 Kollmorgen Seidel GmbH & Co. KG Verkaufsniederlassung West Lilienstraße 3 42719 Solingen Tel.: +49(0)212 - 2 30 77 99 Fax: +49(0)212 - 2 30 77 97 Kollmorgen Seidel GmbH & Co. KG Verkaufsniederlassung Mitte Bussardweg 38 61118 Bad Vilbel Tel.: +49(0)6101 - 55 866 00 Fax: +49(0)6101 - 55 866 06 Kollmorgen Seidel GmbH & Co. KG Verkaufsniederlassung Süd-West Lessingstr. 41 75015 Bretten Tel.: +49(0)7252 - 97 39 040 Fax: +49(0)7252 - 97 39 055 Kollmorgen Seidel GmbH & Co. KG Verkaufsniederlassung Süd-Ost Landsbergerstr. 17 86947 Weil Tel.: +49(0)8195 - 99 92-50 Fax: +49(0)8195 - 99 92-33 Servo-Dyn Technik GmbH Münzgasse 10 01067 Dresden Tel.: +49(0)351 - 49 05 793 Fax: +49(0)351 - 49 05 794	<u>Dänemark / Denmark / Danemark</u> DIGIMATIC A/S "Laerkensfeldt" Aalkaergaardvej 20 8700 Horsens Nord Tel.: +45 - 75 65 66 66 Fax: +45 - 75 65 68 33 <u>Finnland / Finland / Finlande</u> Drivematic OY Hevoskenkä 4 28430 Pori Tel.: +358 - 2 - 61 00 33 11 Fax: +358 - 2 - 61 00 33 50 <u>Frankreich / France / France</u> Kollmorgen Seidel GmbH & Co. KG Parc technologique St.Jacques 2 rue Pierre et Marie Curie 54320 Maxéville Tel.: +33(0)3 83 95 44 80 Fax: +33(0)3 83 95 44 81 Kollmorgen Seidel GmbH & Co. KG 216 Lotissement Les Peiffendes Le Sonnant d'Uriage 38410 Uriage Tel.: +33(0)4 76 59 22 30 Fax: +33(0)4 76 59 22 31 <u>Großbritannien / Great Britain / Royaume-Uni</u> Kollmorgen PO Box 147, KEIGHLEY West Yorkshire, BD21 3XE Tel.: +44(0)15 35 - 60 76 88 Fax: +44(0)15 35 - 68 05 20 Heason Technologies Group Claremont Lodge Fontwell Avenue Eastergate Chichester PO20 6RY Tel.: +44(0)12 43 - 54 54 00 Fax: +44(0)12 43 - 54 45 90	<u>Italien / Italy / Italie</u> M.C.A. s.r.l. Via f. Turati 21 20016 Pero (Mi) Tel.: +39(0)02 - 33 91 04 50 Fax: +39(0)02 - 33 90 85 8 <u>Niederlande / Netherlands / Pays-Bas</u> Dynamic Drives Wattstraat 26f 2723 RC Zoetermeer Tel.: +31(0)79 - 59 39 214 Fax: +31(0)79 - 59 39 840 <u>Schweden / Sweden / Suède</u> S D T AB 25467 Helsingborg Tel.: +46(0)42 - 380 800 Fax: +46(0)42 - 380 813 Stockholm 12030 Stockholm Tel.: +46(0)8 - 640 77 30 Fax: +46(0)8 - 641 09 15 Göteborg 42671 Västra Frölunda Tel.: +46(0)31 - 69 62 60 Fax: +46(0)31 - 69 62 69 <u>Schweiz / Switzerland / Suisse</u> Kollmorgen Seidel GmbH & Co. KG Bühnrain 30 8052 Zürich Tel.: +41(0)1 - 300 29 65 Fax: +41(0)1 - 300 29 66 <u>Spanien / Spain / Espagne</u> BROTOMATIC S.L. C/San Miguel de Acha, 2 Pab.3 01010 Vitoria (ALAVA) Tel.: +34 945 - 24 94 11 Fax: +34 945 - 22 78 32
---	---	---

Systempartner / System partners / Partenaires du système

<u>Bundesrepublik Deutschland / Germany / Allemagne</u> Werner P. Hermes Ingenieurbüro Turmstr. 23 40750 Langenfeld Tel.: +49(0)212 - 65 10 55 Fax: +49(0)212 - 65 10 57 EAT GmbH Elektronische Antriebstechnik Hanferstraße 23 79108 Freiburg Tel.: +49(0)761 - 13 03 50 Fax: +49(0)761 - 13 03 555 IBK Ingenieurbüro Keßler GmbH Dachtmisser Str. 10 21394 Kirchgellersen Tel.: +49(0)4135 - 12 88 Fax: +49(0)4135 - 14 33 MACCON GmbH Kühlbachstr. 9 81543 München Tel.: +49(0)89 - 65 12 20-0 Fax: +49(0)89 - 65 52 17	<u>Großbritannien / Great Britain / Royaume-Uni</u> Motor Technology Ltd. Unit 1 Chadkirk Industrial Estate Otterspool Road Romiley, Stockport Cheshire SK6 3LE Tel.: +44(0)161 - 42 73 641 Fax: +44(0)161 - 42 71 306 <u>Niederlande / Netherlands / Pays-Bas</u> Kiwiet Ingenieurbüro Helenaveenseweg 35 5985 NK Panningen (Grashoek) Tel.: +31(0)77 - 30 76 661 Fax: +31(0)77 - 30 76 646 <u>Schweiz / Switzerland / Suisse</u> Boby Servo Electronic AG Zentralstr. 6 6030 Ebikon Tel.: +41(0)41- 440 - 77 22 Fax: +41(0)41- 440 - 69 43 <u>Ungarn / Hungary / Hongrie</u> Q-TECH Mernöki Szolgáltató Kft. 1161 Budapest Batthyány u. 8. Tel.: +36 (1) 405 - 33 38 Fax: +36 (1) 405 - 91 34	<u>Italien / Italy / Italie</u> Servo Tecnica Viale Lombardia 20 20095 Cusano Milanino (MI) Tel.: +39 (0)02 - 66 42 01 Fax: +39 (0)02 - 66 40 10 20 <u>Türkei / Turkey / Turquie</u> Robotek Otomasyon Teknolojileri Ali Nihat Tarlan CAD. Kartal Sk. No: 16/7 Üstbostancı YSTANBUL Tel: +90 216 464 50 64 pbx Fax: +90 216 464 50 72 <u>Griechenland / Greece / Grèce</u> Alpha Motion 5 - 7 Alkamenos Str. 104.39 Athens Tel.: +30 1 82 27 470 Fax: +30 1 82 53 787 <u>Australien / Australia / Australie</u> Motion Technologies PTY. Ltd. 1/65 Alexander Avenue Taren Point NSW 2229 Sydney Tel.: +61 (0)295 24 47 82 Fax: +61 (0)295 25 38 78
--	--	---

Kollmorgen Seidel GmbH & Co. KG

Hausanschrift

Wacholderstr. 40-42
D - 40489 Düsseldorf
Tel.: +49(0)203 - 99 79 - 0
Fax: +49(0)203 - 99 79 - 155
Internet : <http://www.kollmorgen-seidel.de>

Postanschrift

Postfach 34 01 61
D-40440 Düsseldorf

Kollmorgen

Motion Technologies Group

201 Rock Road
Radford, VA 24141, USA
Tel.: +1 540 - 639 - 24 95
Fax: +1 540 - 731 - 08 47
Internet : <http://www.kollmorgen.com>